

Exterior maintenance tips



 SageSure

Have your chimney cleaned and repair any loose bricks

Check for decay on soffits or fascia

Replace any missing or loose shingles, check for sinking or curling (confirm no more than two layers)

Remove dead branches and trim limbs that hang on your home

Check the seals on your windows and doors



Clean gutters and make sure they are properly secured to the home, with no bending or sagging

Look for cracks or signs of weakness in the foundation, and repair if necessary

Remove or repair hazards that could result in injury, check sidewalks, balconies, steps and railings

Repair any missing or loose siding

Make sure you have proper downspouts that move water away from the home

